



TECHNICAL BULLETIN

Overcoating EnviroPro Timberseal with EnviroPro Endure 1- Pack and 2-Pack water-based polyurethanes

EnviroPro Timberseal is the recommended sealer for use with Endure 1-Pack and 2-Pack, and Endure High Build water-based polyurethanes.

Timberseal can be overcoated after 1.5 hours drying, but there can be situations where the sealer is left to dry for much longer. To ensure adequate adhesion between Timberseal and Endure, the following must to followed:

- If Endure is to be applied on the same day as the Timberseal, then the sealer does not need to be sanded prior to application of the topcoat.
- If Timberseal is allowed to dry overnight, then it must be sanded prior to application of Endure. This ensures that any contaminants or dust that may have settled will be removed.
 - Sand lightly with a worn 150-grit, or 180-grit screen.
 - Perform a quick buff; do not allow the sanding machine to stand in one place, as it will cause “balling” of the product.
 - Timberseal is acrylic, so when allowed to heat up it will clog sandpaper and screens quickly.
 - Thoroughly vacuum surface to remove dust.

Issue Date	18 th November 2008
Issued By	Julia Hall / Keith Chu